	GIMATIC NFC	Page 1 of 8
	PC APPLICATION INSTALLATION INSTRUCTIONS	

REVISIONS		
DATE	REVISION	MAIN CHANGES
2018/03/02	Edition 1.0	First release
2019/03/01	Edition 1.1	Increase of operating speed
2019/07/11	Edition 1.2	Added link functionality




DOCUMENT LAYOUT

- Introduction
- Installation Instructions
- Download
- Troubleshooting
- Main Changes

Introduction
<p>This document describes the installation of software for data exchange with NFC tags provided by Gimatic. RQCB0X is required to interface the software and the reader. Look at step 8 of the installation instructions.</p>

Installation Instructions


1. Connect USB to serial cable to your PC/laptop and assure the system correctly detects the HW (see images below)









2. If the system does not recognize the HW, unplug the USB to serial cable and install its drivers first. The drivers are provided with the software see the download section. Restart procedure from step #1.

3. Execute the installation file with administration rights:

- GimaticSetup.exe (for 64 bits systems)
- GimaticSetup32.exe (for 32 bits systems)











Installation Instructions

4. Execute the Gimatic NFC application and select the same COM port detected by your system on step 1 from drop down menu



5. Connect the RQCBOX to the computer as shown in the picture below.



Installation Instructions

6. Move the TAG (RBQC) under the reader (RAQC or RAQCN) as shown in the picture below



7. Select any operation to perform from the project tree on the left side of the application. Any user can access the reading operations. To access writing operations a password is required: please send a request to info@gimatic.com along with your contact information.

8. Press READ button or fill up the form and press the WRITE button at the center bottom interface. Wait the dialog box to disappear before proceeding with a new reading/writing operation

Download

<http://www.gimatic.com/download/utility>

Troubleshooting



In case the application doesn't show the drop-down menu for the selection of the serial port, please check for the library files of serial communication to be available.

It is possible that these files were deleted during a system update. Close the program, repeat steps 4,5 and restart the program.

Main Changes

Edition 1.0→ First release of application

Edition 1.1→ Increase of the R/W operation on the tag.

Edition 1.2→ Added link functionality: the user can save a link inside the specific area of the tag.